

Stock class

General Driver Rules & Expectations:

1. ALL RULES MUST BE FOLLOWED OR YOU WILL NOT RUN
2. Drivers must wear seat belt, helmet, fire suit jacket and long pants while participating.
3. ALL drivers must attend the drivers meeting.
4. During event you are given 1 minute to make an aggressive hit or will be disqualified.
5. Drivers are not allowed to drink alcohol before they participate. If found with alcohol in system you will not run, no exceptions. ZERO TOLERANCE RULE!!!

THIS IS NOT A SET OF RULES BUT A SET OF GUIDELINES OF HOW TO BUILD YOUR CAR. IF IT DOESN'T SAY YOU CAN SPECIFICALLY DO SOMETHING THEN YOU CAN'T! GRAY AREA'S WILL BE BROUGHT TO LIGHT WITH A TORCH

Car Preparation:

NO PAINTING OR UNDERCOATING OF THE FRAME. NO BUFFING OR GRIDING FRAMES OR BODIES EXCEPT WHERE WELDING IS SPECIFICALLY ALLOWED IN THESE RULES. NO PAINTING IN THE INSIDE OF THE BODY OR CAR. IF THIS IS DONE THE CAR WILL NOT BE INSPECTED.

1. Any American make car can run with the following exceptions: NO 66 AND OLDER Chryslers no restubbing, Chrysler k member cannot be altered, no 4x4, ambulance, hearses, trucks, limousines, convertible frames or full cars etc...
2. All cars must be stock unless modification is specifically stated in these rules.
3. All glass, plastic, chrome, and interior must be removed from car before arriving to the derby.
4. All trailer hitches and braces must be removed.
5. Batteries must be moved to the passenger floorboard and properly secured/covered.
6. All cars must have working brakes. If the car is not able to exhibit the ability to stop it will not be inspected.
7. NO welding other than what is mentioned in this set of rules. If your car is found with any weld, other than what is allowed, and you refuse to fix it to the judge's satisfaction, you and your car will not run.

Bumper:

Bumpers are interchangeable. Any automotive bumper may be used on any car, but no more than one

set of bumper brackets may be used. Bumper brackets may be from any car that is legal to run in your class and on only one side of the frame. Bumper brackets must be one of the two following methods. You may reinforce bumpers on the inside of the bumper. You may trim bumper ends or fold them around. Welding the bumper skins (chrome to inner liner) is allowed. Weld them solid, we do not want them coming off.

Bumper height not to exceed 22" to the bottom of the bumper to the ground and must be a minimum of 14" from the ground to the bottom of the bumper or frame.

Bumpers must be in stock location. The bumper must be completely in front of the frame rails. No part of the bumper may extend back past the front most part of the frame rails Front and rear bumpers may have 4 loops of wire from radiator support/trunk lid or deck (to sheet metal only do not go around core support bolts) to bumper (not frame). These cannot be placed in front of the radiator.

The bumper may be built using a single piece of 5"x5"x1/4" Steel tubing or pipe must be hollow and not capped no points.

Rear Bumper Brackets must follow the front bracket rule, no longer than 10" on the frame.

Wagons do not weld the bumpers to the body.

Bumper brackets:

First way – factory bumper bracket that is legal to a car in your class may not extend any further back than the first 10" of the frame. You can weld bumper brackets to the frame (single pass only).

You can weld bumper brackets and shocks to the bumper. You can weld shocks to shock brackets. You can collapse shocks, and you can bolt the shocks to the towers with 1/2" bolt or less, and it must be done vertically. All brackets must touch the bumper and cannot be cut apart to lengthen.

OR

Second way - INSTEAD of using bumper brackets you are allowed to use ONE 4" wide x 1/4" thick plate extending from your bumper down either a side, or the top, or bottom of the frame choose only one cannot wrap a corner with it and cannot be any longer 10". You are also allowed to wrap this strap around the front of the frame 4" to create an "L" shape. This is to give you enough material to weld your bumper to the strap. Plate Must stay flat no reconfiguring plate.

Do not abuse this rule YOU WILL CUT.

Frame Shortening:

You may cut the frame off flush with the front edge of the body mount hole. If it is a weld on mount leave the remaining portion of the body mount in place. If you remove the body mount completely or relocate it you will not run.

Frame Welding:

NO FRAME WELDING.

NO TILTING.

NO COLD BENDING

Rust Repair – Call before fixing any rust on the frame.

Front Suspension:

Tie Rods and Ball Joints

Stock tie rods and tie rod tubes only not reinforcement.

Stock ball joints no screw in or weld in ball joints STOCK REPLACEMENT ONLY.

No pickup or van tie rod ends.

A-Arms –

A-arms may be welded or bolted down with up to a 5/8" bolt but may not be reinforced. If welded, it may only use up to 2- 2x4x1/8" thick strap per a arm. This strap must weld to the a-frame and cannot extend farther forward or backward than 1" past the widest part of the a-frame. No changing or modifying the a-arm brackets. COIL SPRINGS must be a factory car coil spring for a car that is permitted to run in this class.

Steering box –

May be interchanged but must remain a stock box for a car that is legal in the class you are running.

Pitman arms must remain stock or stock replacement

Idler Arm –

Idler arm must remain stock or interchanged for an idler arm for that is off a car that is legal in the class you are running.

Hubs –

Must remain stock for the spindle you are using no aftermarket hubs or rotors. Brake calipers must remain stock for the stock spindles

Spindles –

Must be stock for a car that is legal in the class you are running, with no modifications.

Rear Suspension:

Leaf springs must be the stock springs that came on the car. You are allowed 4 clamps per leaf pack.

Clamps may be no bigger than 2"x4" x ¼ inch strap. With 2 bolts per strap. Do NOT wrap with tape.

You can change coil springs to a stiffer spring to get your height, do not raise the suspension any other way.

You can bolt, wire, or chain coil springs to rear-end and frame to prevent springs from falling out, do not go through body as this would be another body mount.

You can loop chain or wire (1 loop of 3/8" chain or 4 loops of #9 wires) from rear end to frame in 1 spot on each side, must go around frame, do not bolt the chain to the frame. Max chain link size 3 ¼" OD. You may use a 1" bolt or all thread from your rear end housing to the package tray. You may use both the chain and the 1" bolt to help hold rear end in car.

You cannot leaf spring a factory coil spring car.

Trailing arms:

Both upper and lower must be a factory non loaded trailing arm. Must use a factory trailing arm for a car approved for this class. May shorten or lengthen with 2-inch overlap.

Rear- Ends:

-Use rear end of choice, nothing heavier than 5 lug rear end. Stock appearing.

- You can tilt rear end if you wish.
- Welded or posi-track highly recommended.
- NO BRACING, NO AXLESAVERS.
- Pinion brakes are allowed.
- No changing out rear package trays on frame.
- Rear end control arms cannot be reinforced.

They must attach in stock configuration for the suspension setup you are using. No Hybrid Setups.

Tires:

No split rims, No studded tires. Foam filled or doubled tires are ok. Valve stem protectors are ok. Tire and wheels are unlimited other than what is stated above.

Motor:

- Use motor of choice, motor must be in stock location.
 - NO Distributor protectors or Full cradles!! Lower cradles are allowed.
 - Header Protectors are allowed, Piece of 4X4 ¼" welded around header ONLY and cannot connect to anything.
3. You may run a steel bell and tail.
 4. You may run an aftermarket bell housing, but no other modifications may be done to the transmission.
 5. You are allowed 1 loop of 3/8" chain to the cross member with one link welded per side or bolt it down with 2 – 5/8" bolts with 1.5" washers using the factory holes in the factory tail shaft cone.
 6. May run a bell housing spacer if you have a short bell. May only be attached thru the bell housing bolts.
 7. Slider driveshafts are aloud.

Transmission Cross Member:

-You must use a factory cross member for mounting transmission. This can be out of another car legal for this class, but only if you are not running tranny brace. If running a brace, see option below.

OR

- use a straight piece of 2x2x1/4" tubing, no contours and must be mounted in the stock location on the transmission. You may also use 2x2x4x1/4 inch angle iron to tie cross member to the frame. If using this method you must have 2 ½ inch holes drilled into the tranny cross member to check thickness.

-Tranny cross members must mount in factory location for the car only.

-The transmission cross member must be one piece and must be straight from side to side. The transmission cross member is the only method which the transmission may be tied in.

-Cross member may be welded with single pass only or bolted in.

Body

Body Shaping:

Body may be shaped.

Rust Repair: You can patch rust holes in sheet metal with sheet metal ONLY. Do not cut rust out; weld 2" Beyond rust. 20 GA Sheet metal.

If your frame is rusted through, CALL for instructions on how to fix the rust hole. DO NOT FIX IT WITHOUT CALLING AND EXPECT US TO ALLOW YOU RUN IT.

#9 Wire:

-You may run wire from frame rail underneath back of car, behind rear end with 4 loops of wire or 1 loop of 3/8 chain or cable. This may go around the frame, it may go through a factory frame hole This wire may pass through the trunk floor if you choose.

Radiators:

Radiators must be mounted in the stock location.

NO radiator guards allowed.

Radiator support mounts can be removed, and you can suck the radiator support down solid. Absolutely no body mounts may be moved or added, do not shorten the front of your car and move back past the body mount hole as your car will not run.

If you have to build core support spacers you may not weld it to the body or the frame mount. Core Support Spacers cannot exceed 2" square material.

The front frame must not be shortened to far that the 1" all thread must pass through the factory stamped hole.

Chrysler K-Member cannot be altered.

Hood & Front Clip:

-Hood must have at least a 12-inch square hole cut out in case of fire. Any holes in hood may be bolted back together with 3/8" or less bolts and 1.25" diameter washer no more than a total of 6 bolts allowed to pinch the hood sheet metal back together. You may cut multiple holes but do not exceed the 6 bolts. You are allowed 6 spots to hold the hood on; you must have a minimum of 4 tie down spots. You may have up to 1" all-thread, it may go from the hood to the frame, but must go through the front body

mounts, this may be welded to the frame after it passes through the body mount but may not be nipped underneath the body mount if it is welded. All other tie down spots must be sheet metal to sheet metal only, and the hold down bolts cannot exceed 8" in length!

All hood bolts must be placed outside the windshield bars.

MAX 6 Spots. 1 wrap of 3/8 chain or 1 wrap of #9 wire counts as a fastener. Hinges count as fasteners if used.

- If using angle iron you are allowed 2"x2"x4"x 1/4" Pieces bolted with 1, 1/2" bolts max.
- You may have plates for hood tie down, not to exceed 5x5x1/4" square or 6" x1/4" round.
- Front core support cannot be moved back from its factory location. It must stay bolted to the fenders the same way that it came factory.
- You may cut wheel wells for tire clearance. Fenders may be bolted back together with 5 -3/8" bolts or less with 1.25" diameter washers. No rolling your fenders and welding them. If you wrap or fold your fenders around the front of the core support do not exceed 4 - 3/8" bolts with 1.25" washers to bolt back to the core support of fender.

Windshield Bar & Firewall:

You are allowed to cut firewall out for engine clearance do not use to reinforce the car.

Window Bar For safety, all cars must have (2) windshield bars extending from the roof of the car to the firewall/dash,

straps cannot be any larger than 3/8"x3" flat strap. If and only if you remove the firewall/dash completely between the straps you can connect these 2 bars. The removed part must be completely removed and must be as wide as the vertical bars. The horizontal bars connecting the two vertical bars cannot be any larger than 3/8"x3" straps.

No more than 6" of strap material is allowed on the roof and no more than 6" of strap material allowed on the firewall. Do not go over 6" on roof or firewall or you will cut. Window bars cannot go more than 6 inches past the window opening. Must be at least 14 inches apart at the firewall.

Doors

Drivers door can be plated, Filled with concrete, we want you safe.

-you may weld your front 2 doors solid with 3/8 rod or 3"x1/8" Strap. Rear doors can be wired or chained shut. Do not weld rear doors.

-You are allowed to add bracing to the exterior side of the driver's door. This bracing must not stick any further out than 2" from the door and may not have any sharp edges. You are also allowed to carry the bracing up to 6" past the exterior door seam either forward or backward. The driver door you can weld completely shut with the 3" by 1/8 strapping. No overlap.

Cage

All cage material must be no larger than 6" od, unless specified for specific rule smaller. It must be a minimum of 4" off the floor everywhere except the down legs going straight down that includes being 4" off of the transmission/tunnel. No cage material may be within 6" of the firewall and any part of the engine or components and be minimum of 4" off the transmission tunnel which cannot be altered. You may weld a bar behind the seat from doorpost to doorpost, it can be an X do not connect directly to frame, and you may also have a single bar (with no extensions), across your dash area to replace you dash. You may run a bar connecting the dash bar and seat bar inside of the front doors only. You must have a roll loop behind the seat, which must be welded to the floor and may be welded or bolted to the roof. You may also weld a steering column to the cage. Side bars including roll over may be a max length of 62 inches long. NO BARS CAN COME IN CONTACT WITH THE FRAME!

Gas Tank Protector - It cannot attach to anything other than your cage. It must be centered between your frame humps. It cannot exceed 24" wide. It can angle in from your roll over protection. It must be a full 3" away from rear sheet metal, which cannot be removed. The bracing must be 4" above all floor sheet metal, which cannot be removed, measured from the highest flat area of the floor in the rear seat area.

Fuel Tank, Oil Coolers, & Transmission Coolers:

Original gas tanks must be removed. You must use a boat tank or well-made fuel cell, and it must be properly secured and covered. Only metal tanks may be used. Fuel line must be secured and fastened properly. Keep away from exhaust. Place fuel cell behind driver's seat or in the center of the car where the back seat use to be. No other source of gas inside the car at all.

Engine oil coolers and transmission coolers are allowed.

These coolers cannot be placed to reinforce the car. No bolts may extend through the frame to create a body mount.

AFTERMARKET PARTS THAT ARE ALLOWED:

- Transmission cooler
- Oil cooler
- Gas and brake pedal
- Shifter
- Headers
- Driveshaft (Sliders)
- Motor mounts with rubber bushing
- Steering column

Trunks

- -Trunks cannot be welded. Trunks can have 6 spots holding trunks down max. Hinges count as 2 of your fasteners.
- Trunk lids must remain on hinges.
- You are allowed to tuck trunk.
- You are allowed to wedge trunk.
- You can use 4 4x2" pieces of strap to secure trunk.
- (2) 1" All-thread may go from the trunk lid to the frame or trunk pan, it must pass through a body mount.
- 1 wrap of 3/8 chain, one wrap of # 9 wire, or 1 inch all thread counts as a fastener.

You can change the 4 rear body mounts and suck the body down tight all other body mounts should be stock and untouched.

You are allowed 1 inch all thread in the front 2 body mounts and the rear 4 body mounts all other mounts must remain stock. With stock body mount bushings.

-all Wagons must remove all rear decking and seat components.

All other rules above must be followed.

03 & Newer Rules:

2. Must run the factory aluminum cradle, NO added metal.
3. Struts, spindles and a arms may be switched to a direct bolt on. No cutting, welding, and fabbing to make it work.
5. Repair plates may not be used to tie cradle into the rails.

6. Watts link conversions are allowed.

7. Must follow all other rules

THIS IS NOT A SET OF RULES BUT A SET OF GUIDELINES OF HOW TO BUILD YOUR CAR.

IF IT DOESN'T SAY YOU CAN SPECIFICALLY DO SOMETHING THEN YOU CANT.

JUDGES DECISION IS FINAL!!!

FIX IT PLATES YOU ARE ALLOWED 3 4"X6"X1/4" PLATE PER FRAME RAILS. PRE RAN CARS ONLY!!!

FIX IT PLATES MUST BE ON THE OUTSIDE OF THE FRAME AND A MINIMUM OF 1" BETWEEN WELDS.

Frame MUST have visible damage to have a plate on it.

NO Plating unbent cars.

CALL SCHUYLER TOTTEN OR ALAN GARRETT AT 719-285-9031 FOR ANY QUESTIONS REGARDING RULES OR PRE-REGISTRATION.